


Auxiliary contact timing diagrams OS200 – OES800

Disconnect
switches
Fusible

OS200 - OS600



OES800

Catalog number	Auxiliary contact	Contact configuration
OES800	OZXK-1	1 N.O. & 1 N.C.
	OZXK-2	2 N.O. & 2 N.C.
	OZXK-3	4 N.O. & 4 N.C.
	OZXK-4	2 N.O.
	OZXK-5	4 N.O.
	OZXK-6	8 N.O.

