


ProgramaCube® Function Selector

For KRPS, KSPS, KSPU, HRPS, HRPV, HRIU

Single Adjustment Functions



Function Diagrams



Legend

V = Voltage R = Reset S1 = Initiate Switch
 TD1, TD2 = Time Delay C = Count
 P = Pulse Duration t = Incomplete Time Delay
 NO = Normally Open NC = Normally Closed
 —||— = Undefined time

Note: If S1 is closed when input voltage is applied, the function starts and the time delay begins. (B, S, TS, US, UB, AM, PSD, FT)