



General information

Catalog number information

Emax, cradle (fixed part) UL



General information

Standard features

Fixed breaker		Drawout breaker	
Manual operated	Electrically operated	Manual operated	Electrically operated
T.U. — PR111/P, LI Aux. SW., 4 Spring charged indicator Flange Accessory support Terminal block Lifting plate	T.U. — PR111/P, LI Motor operator Closing coil Shunt trip Aux. SW., 4 Spring charged indicator Flange Accessory support Terminal block Lifting plate	T.U. — PR111/P, LI Aux. SW., 4 Spring charged indicator Flange Crank Accessory support Sliding contacts Anti-insertion lock Lifting plate	T.U. — PR111/P, LI Motor operator Closing coil Shunt trip Aux. SW., 4 Spring charged indicator Flange Crank Accessory support Sliding contacts Anti-insertion lock Lifting plate

NOTE: Switches provided standard without 4 auxiliary contacts.