





















Components

Pushbutton and pilot light lens inserts^①

Pilot Devices
Type CBK 22mm

Legend	Cap color	Suffix code ^②	Flush button catalog number	Extended button catalog number	Pilot light catalog number	List price
0	White	C21	CBK-KC21	CBK-KC21E	CBK-KC21P	
	Red	C22	CBK-KC22	CBK-KC22E	—	
	Black	C23	CBK-KC23	—	—	
I	White	C24	CBK-KC24	CBK-KC24E	CBK-KC24P	
	Red	C25	CBK-KC25	—	—	
	Black	C26	CBK-KC26	—	—	
II	White	C27	CBK-KC27	CBK-KC27E	CBK-KC27P	
	Red	C28	CBK-KC28	—	—	
	Black	C29	CBK-KC29	—	—	
III	White	C30	CBK-KC30	CBK-KC30E	—	
	Black	C31	CBK-KC31	—	—	
+	White	C32	CBK-KC32	CBK-KC32E	—	
	Red	C33	CBK-KC33	—	—	
	Black	C34	CBK-KC34	—	—	
-	White	C35	CBK-KC35	CBK-KC35E	—	
	Red	C36	CBK-KC36	—	—	
	Black	C37	CBK-KC37	—	—	
	White	C13	CBK-KC13	CBK-KC13E	CBK-KC13P	
	Black	C38	CBK-KC38	—	—	
	White	C39	CBK-KC39	CBK-KC39E	—	
	Black	C40	CBK-KC40	—	—	
	White	C41	CBK-KC41	CBK-KC41E	—	
	Black	C42	CBK-KC42	—	—	
	White	C43	CBK-KC43	CBK-KC43E	—	
	Black	C44	CBK-KC44	—	—	
	White	C45	CBK-KC45	CBK-KC45E	—	
	Black	C46	CBK-KC46	—	—	
	White	C14	CBK-KC14	CBK-KC14E	CBK-KC14P	
	Black	C47	CBK-KC47	CBK-KC47E	—	
	White	C48	CBK-KC48	—	—	
	Black	C49	CBK-KC49	CBK-KC49E	—	
	White	C50	CBK-KC50	—	—	
	Black	C51	CBK-KC51	CBK-KC51E	—	
	White	C52	CBK-KC52	—	—	
	Black	C53	CBK-KC53	CBK-KC53E	—	
	White	C54	CBK-KC54	—	—	
	Black	C55	CBK-KC55	CBK-KC55E	—	
	White	C56	CBK-KC56	—	—	
	Black	C57	CBK-KC57	CBK-KC57E	—	
	White	C58	CBK-KC58	—	—	
	Black	C59	CBK-KC59	CBK-KC59E	—	
	White	C60	CBK-KC60	—	—	
	Black	C61	CBK-KC61	CBK-KC61E	—	
	White	C62	CBK-KC62	—	—	
	Black	C63	CBK-KC63	CBK-KC63E	—	
	White	C64	CBK-KC64	—	—	
	Black	C65	CBK-KC65	CBK-KC65E	—	
	White	C66	CBK-KC66	—	—	
	Black	C78	—	—	CBK-KC78P	
	White	C79	—	—	CBK-KC79P	
	White	C76	CBK-KC76	—	—	
	White	C77	CBK-KC77	—	—	
	White	C80	CBK-KC80	—	—	

\$.90

8

^① Illuminated pushbuttons and pilot lights must use white insert.

^② For extended pushbuttons, insert "E" at the end of the catalog number. For pilot lights, insert "P" at the end of the catalog number.