Air circuit breakers
Installed optional features
UL & IEC

1. – 20. Options for trip units

Item	Factory installation list price adder	Field installation catalog number	Field install. list price
1. Trip unit PR111/P-A LI (UL version)	—	PR111/P-A-LI	**$ 1089**
2. Trip unit PR111/P-A LSI (UL version)	**$ 515**	PR111/P-A-LSI	**1604**
3. Trip unit PR111/P-A LSIG (UL version)	**1208**	PR111/P-A-LSIG	**2297**
4. Trip unit PR112/P-A LSI (UL version)	**2210**	PR112/P-A-LSI	**3299**
5. Trip unit PR112/P-A LSIG (UL version)	**2904**	PR112/P-A-LSIG	**3993**
6. Trip unit PR112/PD-A LSI (UL version)	**6890**	PR112/PD-A-LSI	**7979**
7. Trip unit PR112/PD-A LSIG (UL version)	**7583**	PR112/PD-A-LSIG	**8672**
8. Trip unit PR113/P-A-LSIG (UL version)	**7323**	PR113/P-A-LSIG	**8412**
9. Trip unit PR113/PD-A-LSIG (UL version)	**12,002**	PR113/PD-A-LSIG	**13,091**
10. Trip unit PR111/P LI (IEC version)	—	PR111/P-LI	**1089**
11. Trip unit PR111/P LSI (IEC version)	**515**	PR111/P-LSI	**1604**
12. Trip unit PR111/P LSIG (IEC version)	**1208**	PR111/P-LSIG	**2297**
13. Trip unit PR112/P LSI (IEC version)	**2210**	PR112/P-LSI	**3299**
14. Trip unit PR112/P LSIG (IEC version)	**2904**	PR112/P-LSIG	**3993**
15. Trip unit PR112/PD LSI (IEC version)	**6890**	PR112/PD-LSI	**7979**
16. Trip unit PR112/PD LSIG (IEC version)	**7583**	PR112/PD-LSIG	**8672**
17. Trip unit PR113/PLSIG (IEC version)	**7323**	PR113/P-LSIG	**8412**
18. Trip unt PR113/PDLSIG (IEC version)	**12,002**	PR113/PD-LSIG	**13,091**
19. Mechanical trip indication (manual reset)	**188**	KE6TSM	**188**
20. Mechanical trip indication and bell alarm	**348**	KE6TBA	**348**

21. – 27. Electrical and mechanical accessories

Item	Factory installation list price adder	Field installation catalog number	Field installation list price
21a. Shunt trip coil (included in the electrically operated breaker)			
Rated voltage			
24V		KE6S0	
30V		KE6S9	
48V		KE6S8	
60V		KE6S7	
110/120V	**$ 374**	KE6S6	**$ 374**
125/127V		KE6S5	
220/240V		KE6S4	
250V		KE6S3	
380/400V		KE6S2	
440/480V		KE6S1	
21b. Second shunt trip coil (includes accessory support) ①			
24V		KE6S0-2	
30V		KE6S9-2	
48V		KE6S8-2	
60V		KE6S7-2	
110/120V	**456**	KE6S6-2	**456**
125/127V		KE6S5-2	
220/240V		KE6S4-2	
250V		KE6S3-2	
380/400V		KE6S2-2	
440/480V		KE6S1-2	
22.Closing coil (included in the electrically operated breaker)			
Rated voltage			
24V		KE6C0	
30V		KE6C9	
48V		KE6C8	
60V		KE6C7	
110/120V	**374**	KE6C6	**374**
125/127V		KE6C5	
220/240V		KE6C4	
250V		KE6C3	
380/400V		KE6C2	
440/480V		KE6C1	
23. Spring charging motor with limit switch and electrical indication charged spring (included in the electrically operated breaker)			
Rated voltage			
24/30V		KE6M9	
48/60V	**1613**	KE6M7	**1613**
100/130V		KE6M5	
220/250V		KE6M3	
Spring charged signal only	**73**	KE6SC	**73**

① Order as alternative to UV trip.