Components
Pushbutton and pilot light lens inserts①

Legend	Cap color	Suffix ② code	Flush button catalog number	Extended button catalog number	Pilot light catalog number	List price
0	White Red Black	C21 C22 C23	CBK-KC21 CBK-KC22 CBK-KC23	CBK-KC21E CBK-KC22E —	CBK-KC21P — —	
I	White Red Black	C24 C25 C26	CBK-KC24 CBK-KC25 CBK-KC26	CBK-KC24E — —	CBK-KC24P — —	
II	White Red Black	C27 C28 C29	CBK-KC27 CBK-KC28 CBK-KC29	CBK-KC27E — —	CBK-KC27P — —	
III	White Black	C30 C31	CBK-KC30 CBK-KC31	CBK-KC30E —	— —	
+	White Red Black	C32 C33 C34	CBK-KC32 CBK-KC33 CBK-KC34	CBK-KC32E — —	— — —	
–	White Red Black	C35 C36 C37	CBK-KC35 CBK-KC36 CBK-KC37	CBK-KC35E — —	— — —	
	White Black	C13 C38	CBK-KC13 CBK-KC38	CBK-KC13E —	CBK-KC13P —	
	White Black	C39 C40	CBK-KC39 CBK-KC40	CBK-KC39E —	— —	
	White Black	C41 C42	CBK-KC41 CBK-KC42	CBK-KC41E —	— —	
	White Black	C43 C44	CBK-KC43 CBK-KC44	CBK-KC43E —	— —	
	White Black	C45 C46	CBK-KC45 CBK-KC46	CBK-KC45E —	— —	
	White	C14	CBK-KC14	CBK-KC14E	CBK-KC14P	
	White Black	C47 C48	CBK-KC47 CBK-KC48	CBK-KC47E —	— —	
	White Black	C49 C50	CBK-KC49 CBK-KC50	CBK-KC49E —	— —	**$ .90**
	White Black	C51 C52	CBK-KC51 CBK-KC52	CBK-KC51E —	— —	
	White Black	C53 C54	CBK-KC53 CBK-KC54	CBK-KC53E —	— —	
	White Black	C55 C56	CBK-KC55 CBK-KC56	CBK-KC55E —	— —	
	White Black	C57 C58	CBK-KC57 CBK-KC58	CBK-KC57E —	— —	
	White Black	C59 C60	CBK-KC59 CBK-KC60	CBK-KC59E —	— —	
	White Black	C61 C62	CBK-KC61 CBK-KC62	CBK-KC61E —	— —	
	White Black	C63 C64	CBK-KC63 CBK-KC64	CBK-KC63E —	— —	
	White Black	C65 C66	CBK-KC65 CBK-KC66	CBK-KC65E —	— —	
	White	C78	—	—	CBK-KC78P	
	White	C79	—	—	CBK-KC79P	
	White	C76	CBK-KC76	—	—	
	White	C77	CBK-KC77	—	—	
	White	C80	CBK-KC80	—	—	

① Illuminated pushbuttons and pilot lights must use white insert.
② For extended pushbuttons, insert “E” at the end of the catalog number. For pilot lights, insert “P” at end of the catalog number.